

© Copyright 2008 Kevin W. Smith & Unilever Research Colworth

All text, data, images, backgrounds and graphics in this presentation are copyrighted by Unilever Research Colworth, Sharnbrook, MK44 1LQ, UK. Use or copying in any way or any format of this presentation or any part of it is strictly prohibited without prior written permission from the copyright holder. All Rights Reserved.



Effect of SSS and SOS on crystallisation in model fat blends

Kevin W. Smith,

Jeroen Vereecken, Imogen Foubert, Koen Dewettinck, Loek Favre







Introduction



- Drive to reduce *trans* fats in the diet
 - Trans required to supply solid fat
 - Alternative is saturated
- Challenge to retain functionality without compromising on saturated fat levels
- Need to optimise triglyceride composition
 - E.g. SOS has ²/₃ the saturates of SSS yet both provide similar solid at room temperature

Approach



- Blends formulated to compare effect of:
 - SSS and SOS level
 - Saturate type: Stearic (C18) or Palmitic (C16)
 - At constant overall saturated fat level 30%
- Blend components:
 - Palm stearin
 - Palm mid fraction
 - Fully hydrogenated soybean oil
 - Shea stearin
 - High oleic sunflower oil

PPP POP StStSt StOSt OOO

Triglyceride Composition



S = saturated, O = oleic, L = linoleic

Fatty Acid Composition





Measurements



- Solid Fat Content by pNMR
 - Serially tempered (IUAC 2.150)
- Isothermal crystallisation by DSC at 15℃ & 20℃
 - 'normal'
 - 'stop-and-return'
- Crystal structure/morphology by light microscopy at 15℃ and 20℃

Isothermal DSC Normal vs Stop & Return



Effect of PPP/POP on SFC



Effect of StStSt/StOSt on SFC



Comparison of P with St by SFC



Solid Fat Content



- SSS gives rise to higher SFC at high T but lower at low T
 - SSS provides solid at high T
 - Both SSS & SOS provide solid at low T
 - For same saturated fat, 1% SSS can be replaced with 1.5% SOS
- Final melting point increases with SSS
- "Cross-over" point is higher for St blends than for P
 - St TAG have higher melting points than P TAG
- Overall, SFC slightly higher for St blends
 - Lower solubility of St TAG in liquid oil compared to P TAG

Isothermal DSC







Peak areas at 15°C











Isothermal DSC



- SSS acts as a seeding agent for SOS crystallisation
 - PPP more effective than StStSt
 - P blends crystallised faster than St blends
 - Despite lower undercooling
- P blends behave similarly at 15 °C & 20 °C
 - Higher PPP leads to faster crystallisation
- St blends show differences between 15 ℃ & 20 ℃
 - Similar behaviour to P at 20 °C
 - S-L fastest and S-M slowest at 15℃
- Evident that crystallisation begins before reaching isothermal temperature

PPP/POP by S&R at 15°C



PPP/POP by S&R at 20°C



StStSt/StOSt by S&R at 15°C



StStSt/StOSt by S&R at 20°C



Example: Blend S-M S&R, 10min, 15



PPP/POP peak evolution at 15 C



PPP/POP peak evolution at 20 C



StStSt/StOSt peak evolution at 1520///



StStSt/StOSt peak evolution at 2020///



Stop and Return DSC



- Both P & St blends
 - Some crystallisation occurred during cooling
 - Except for lowest SSS
 - Likely to be polymorphic transformation during crystallisation
 - Disappearance of low melting peak faster for P than St
 - Initial crystallisation in, e.g. α , which transforms to β'
- P blends
 - Similar to 'normal' DSC
 - High PPP gives faster crystallisation
 - One-step crystallisation
 - Suggests co-crystallisation of PPP & POP
- St blends
 - Lesser effect of StStSt on crystallisation at 15°C
 - Possibly due to larger degree of undercooling
 - Two step crystallisation evident
 - Slower crystallisation than P blends, except at low SSS
 - PPP better seed for POP than is StStSt for StOSt
 - Polymorphic transformation evident on re-heating

Microstructure, crystallised at 15 3 100

Storage time

0 1 month

200 μm

200 um

P-H



Microstructure, crystallised at 15 2000

Storage time

0

1 month













Microstructure, crystallised at 20 °C

Storage time

1 month







Microstructure, crystallised at 20 2000

Storage time





S-H



Microstructure



- Crystal size decreases as SSS increases
 - Much larger in blends without SSS
 - Seeding effect of SSS
- Crystal size very slightly larger at 20 ℃ compared to 15 ℃
 - Faster nucleation rate at 15℃
- All crystals increase in size during storage
 - Low SSS blends show much greater size increase
 - Possibly due to polymorphic transformation

Summary

gi Un

- Higher SSS levels lead to:
 - Faster crystallisation
 - Higher melting
- PPP has a greater seeding effect on POP than does StStSt on StOSt
- Evidence for polymorphic transformation occurring during crystallisation
 - Occurs more rapidly for P than St blends
- Larger crystals form with low levels of SSS
 - Recrystallise on storage to even greater size
- Important to formulate a fat to have the right proportion of SSS and SOS, as well as P and St
 - Crystallisation behaviour
 - Structure
 - Storage stability





- Ria Dhian Anggreni
- IOI Loders Croklaan BV, Sponsorship

